Get started with Session Viewer

1

Go to
www.laerdal.com/downloads

Download and install the
Session Viewer software

2

Connect SimPad
to PC

3

Locate the device on your
PC and open the Logs folder

Logs

4

Click to open
any session file

bls_session_example.ssx

5

The Session Viewer application opens and you can toggle between three different modes